

- Installation Instructions
- PDFEquipment Gr..

- Bond network equipment to grounding strip or grounding busbar
- Jumper kit available with both ends factory terminated to provide a bolt -on solution
- Jumper kit available with one end factory terminated to attach to the grounding strip or grounding busbar; free end accommodates unique equipment terminations
- Use jumpers with 90° bent lug, on grounding strip side, for high density grounding requirements up to one ground point per RU
- Use jumpers with 45° bent lugs, on grounding strip side, for improved cable management
- Use 24" jumpers when network equipment ground point is located near the grounding strip side of the rack or cabinet
- Use 36" jumpers when network equipment ground point is located away from the grounding strip side of the rack
- Engineered to comply with US and International grounding requirements