



# FOR USE WITH PANDUIT® PAN-WAY™ TWIN-70 SURFACE RACEWAY



## PAN-WAY™ TWIN-70 TRANSITION FITTING

PART NUMBERS: T702TRL, T702TR, T702TRI


### INSTALLATION INSTRUCTIONS

©Panduit Corp. 1999





Made in U.S.A.



### POWER OR DATA(TRANSITION TO



The mounting hardware used to secure the raceway shall be appropriate for the mounting surface.



For Technical Assistance call: 888-506-5400, Ext. 8287





---

# TWIN-70 TRANSITION FITTING INSTALLATION INSTRUCTIONS

---

## POWER OR DATA(TRANSITION TO T70)




---



---


## UNDIVIDED TRANSITION W/CROSSOVER

---




TWIN-70 TRANSITION FITTING INSTALLATION INSTRUCTIONS


UNDIVIDED TRANSITION W/CROSSOVER (LD VERSION)CONTINUED



UNDIVIDED TRANSITION W/CROSSOVER (T-70 VERSION)




DIVIDED TRANSITION (LD OR T-45 VERSIONS)



# TWIN-70 TRANSITION FITTING INSTALLATION INSTRUCTIONS

## DIVIDED TRANSITION (LD VERSION)



## DIVIDED TRANSITION (T70)

