

**Industrial Ethernet
EBR-MODULE RS232**

Weidmüller Interface GmbH & Co. KG
Klingenbergstraße 26
D-32758 Detmold
Germany
Fon: +49 5231 14-0
Fax: +49 5231 14-292083
www.weidmueller.com

Product image**Module for saving and loading a device
configuration**

- Reduced system downtime by simple reconfiguration if equipment is swapped over
- Automatic loading of the saved configuration possible after device restart
- Compact and robust design
- Useable with all Weidmüller managed switches and industrial WLAN devices

General ordering data

Type	EBR-MODULE RS232
Order No.	1241430000
Version	Configuration module, IP40, 0 °C...60 °C
GTIN (EAN)	4050118029086
Qty.	1 pc(s).

Industrial Ethernet EBR-MODULE RS232

Weidmüller Interface GmbH & Co. KG
Klingenbergstraße 26
D-32758 Detmold
Germany
Fon: +49 5231 14-0
Fax: +49 5231 14-292083
www.weidmueller.com

Technical data

Dimensions and weights

Width	32.5 mm	Width (inches)	1.28 inch
Height	12 mm	Height (inches)	0.472 inch
Depth	97 mm	Depth (inches)	3.819 inch
Net weight	50 g		

EMC conformity and approvals

EMC standards	FCC Part 15, CISPR (EN55022) Class A, EN 61000-4-2 (ESD), Stage 2, EN 61000-4-3 (RS), Stage 3, EN 61000-4-4 (EFT), Stage 3, EN 61000-4-5 (surge voltage), Stage 3, EN 61000-4-6 (CS), Stage 3
---------------	---

Environmental conditions

Humidity	5 to 95 % (non-condensing)	Operating temperature, max.	60 °C
Operating temperature, min.	0 °C	Storage temperature, max.	70 °C
Storage temperature, min.	-20 °C		

Guarantee

Time interval	5 years
---------------	---------

Power supply

Connection type	RJ45-Port, RS232
-----------------	------------------

Technical data

Cable length	0.35 m	Housing main material	PVC casting
Protection degree	IP40	Type of fixing	M4 screw (< 4 mm)

Classifications

ETIM 6.0	EC000734	ETIM 7.0	EC000734
eClass 9.0	19-17-92-90	eClass 9.1	19-17-01-25
eClass 10.0	19-17-92-90		

Approvals

ROHS	Conform
------	---------

Downloads

Approval/Certificate/Document of Conformity	EU Declaration of Conformity
Brochure/Catalogue	CAT 9 IETH 18/19 EN
Engineering Data	STEP
User Documentation	Hardware Installation Guide