
Staggered jumper; 5-way; insulated; light gray

https://www.wago.com/2002-475







Color: ■ light gray

Electrical data

Ratings per IEC/EN	
Nominal voltage (III/3)	400 V
Rated impulse withstand voltage (III / 3)	6 kV
Rated current	25 A

ysic	

· · · · · ·		4
Width	24.7 mm / 0.972 inches	
lumner assignment	1-2-3-4-5	

Material data	
Note (material data)	
	Information on material specifications can be found here
Color	light gray
Fire load	0.064 MJ
Weight	2.5 g

Environmental requirements				
Environmental Testing (Environmental Conditions)		Environmental Testing (Environmental Conditions)		
Test specification Railway applications – Rolling stock – Electronic equipment	DIN EN 50155 (VDE 0115-200):2022-06	Test duration per axis	10 min. 5 h	
		Test directions	X, Y and Z axes X, Y and Z axes	
Test procedure DIN EN 61: Railway applications – Rolling stock equipment – Shock and vibration tests	DIN EN 61373 (VDE 0115-0106):2011-04		X, Y and Z axes	
		Monitoring for contact faults/interruptions	Passed	
Spectrum/Installation location	Service life test, Category 1, Class A/B	Voltage drop measurement before and after each axis	Passed	
Function test with noise-like vibration	Test passed according to Section 8 of the standard	Simulated service life test through increased levels of noise-like vibration	Test passed according to Section 9 of the standard	
Frequency	$f_1 = 5 \text{ Hz to } f_2 = 150 \text{ Hz}$ $f_1 = 5 \text{ Hz to } f_2 = 150 \text{ Hz}$	Extended test scope: Monitoring for contact faults/interruptions	Passed Passed	
Acceleration	0.101g (highest test level used for all axes) 0.572g (highest test level used for all axes) 5g (highest test level used for all axes)	Extended test scope: Voltage drop measurement before and after each axis	Passed Passed	
		Shock test	Test passed according to Section 10 of the standard	

https://www.wago.com/2002-475

stock equipment



Environmental Testing (Environmental Conditions)

Shock form Half sine

Shock duration 30 ms

Number of shocks per axis 3 pos. und 3 neg.

Vibration and shock stress for rolling Passed

Commercial data	
Product Group	22 (TOPJOB S)
eCl@ss 10.0	27-14-11-40
eCl@ss 9.0	27-14-11-40
ETIM 9.0	EC000489
ETIM 8.0	EC000489
PU (SPU)	25 pcs
Packaging type	Bag
Country of origin	DE
GTIN	4055143692281
Customs tariff number	85366990990

Environmental Product Compliance RoHS Compliance Status Compliant, No Exemption

Approvals / Certificates

Declarations of conformity and manufacturer's declarations




Approval	Standard	Certificate Name
Railway WAGO GmbH & Co. KG	-	Railway Ready

Downloads Environmental Product Compliance Compliance Search Environmental Product Compliance 2002-475

Documentation						
Additional Information			Bid Text			
Technical Section	pdf 2246.92 KB	$\underline{\downarrow}$	2002-475	19.02.2019	xml 2.62 KB	$\underline{\downarrow}$
			2002-475	27.04.2017	doc 24.00 KB	<u>↓</u>

https://www.wago.com/2002-475





Installation Notes

Commoning





Orient the staggered jumpers' red stripes on the inside.

Insert the staggered jumper and push down until it hits the backstop.

Commoning two potentials in one single jumper slot via extremely slim staggered jumpers.


Commoning



Orient the staggered jumpers' red stripes on the inside.

Insert the staggered jumper and push down until it hits the backstop.

Commoning



Removing a staggered jumper: Insert the operating tool between the staggered jumpers, then lift up the jumper.

https://www.wago.com/2002-475



Commoning



Staggered jumper (seven contacts)Breaking off contact lugs. Individual jumper contacts can be broken off by bending them. The remaining piece of insulation will meet requirements for clearances and creepage distances.



Staggered jumpers Marking with a felt-tip pen.



Staggering jumpers in a single jumper slot:

Custom staggered jumpers can be created, e.g., for bridging over a terminal block with a different potential. Make sure that only one contact lug is in contact with the terminal block.

The contact lugs of the customized staggered jumpers contact the terminal blocks via the gaps created in the second jumper. Insert and press the ready-made jumper assembly into the jumper slot until it hits the backstop.

Subject to changes. Please also observe the further product documentation!

Current addresses can be found at:: www.wago.com